

TEST REPORT

Fine ceramics (advanced ceramics, advanced technical ceramics) — Test method for air purification performance of photocatalytic materials — Part 2: Removal of acetaldehyde JIS R 1701–2:2008

On behalf of:

Kon Corporation Co.,Ltd.

22646 Matsunokibaru, Yamauchi-Cho, Takeo-City,

Saga, JAPAN

Performed by:

Yoshihiro Maki

Chairman

Kanagawa Academy of Science and Technology

KSP, 3-2-1 Sakado, Takatsu-ku, Kawasaki City,

Kanagawa, 213-0012, JAPAN

TEL. +81-44-819-2105

センター長	センター長 代理	グループ リーダー	担当者	公印使用者

-----NOTE-----

Unless otherwise specified, no part of this report may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from KAST.

1. Subject matter of the work

The subject matter of this test report is the determination of the air purification performance of materials that contain a photocatalyst or have a photocatalytic film on the surface.

2. Test method

Fine ceramics (advanced ceramics, advanced technical ceramics) — Test method for air-purification performance of semiconducting photocatalytic materials — Part 2: Removal of acetaldehyde (JIS R 1701-2:2008)

3. Overview of the tested samples

Sagancoat Photocatalyst coating agent TPX-HL

4. Reporting matters under the provision of JIS

a) JIS standard number; test period; laboratory conditions; tester

JIS R 1701-2:²⁰⁰⁸

25/10/2013; 23.5±1°C, 65±1%

19/11/2013; 23.5±1°C, 65±1%

20/11/2013; 23.5±1°C, 65±1%

Norihisa Muramatsu

b) Description of the sample (material, size, shape, etc.)

Photocatalyst coated polyester cloth with the dimensions : 50 mm × 100 mm × 0.2 mm

c) Description of test equipment

1. Precision humidity generator: SRG-1R-1L (DaiichiKagaku Inc.)

Humidity discharge range: 0-100%rh; Rated air volume: 1.0 L/min

2. Hydrogen flame ionization detector: GC-2014AFF (Shimadzu)

Detection limit of acetaldehyde and CO₂: 0.01 ppm

3. Gas blender: GB-2C (Kofloc)

Line 1: ≤ 1.0 L/min; Line 2: ≤ 50 mL/min

4. UV irradiation device: custom-made item (Toho Sanso Kogyo Co.,Ltd.)

10 W/m² at the surface of the sample

5. Reactor: custom-made item (Eda Shokai Inc.)

Reactor under the provision of JIS R 1701-2:²⁰⁰⁸

6. Tubing: custom-made item (Toho Sanso Kogyo Co.,Ltd.)

SUS and Teflon

d) Testing conditions

1. Supply concentration of acetaldehyde: 5.0 ppm
2. Conditions of pretreatment: 20 W/m², exposure over 24 h, continual
3. Water-vapour concentration: 1.56 vol%
4. Flow rate: 1.0 L/min
5. Detailed description of light source: FL10BLB×2 (Toshiba)
6. Irradiance: 10 W/m² at the surface of the sample
7. Number of sample: 1
8. Analyser used: Hydrogen flame ionization detector with a methanizer furnace
9. Radiometer used: UV power meter C9536-01, H9958-01(Hamamatsu Photonics)

e) Removal percentage of acetaldehyde and conversion to CO₂ during 1 h of irradiation
For reference, removal percentage of acetaldehyde and conversion to CO₂

Q_A is the quantity of acetaldehyde removed during 1 h of irradiation (μmol/h)

Q_C is the quantity of CO₂ converted from acetaldehyde during 1 h of irradiation (μmol/h)

R_A is the removal percentage of acetaldehyde (%)

R_c is the conversion from acetaldehyde to CO₂ (%)

sample name	Q _A (μmol/h)	Q _c (μmol/h)	R _A (%)	R _c (%)
TPX-HL	6.7	11.8	50.3	43.2

f) Special report

- N/A .